

GUÍA DE SELECCIÓN / SELECTION GUIDE

	T°			P (Bar)			V (m/s)			P-H		
												
MF 245	270			200	150	---	2	3	---			0-14
MF 250	270			100	100	50	1	2	15			0-14
MF 260	270			250	250	20	2	3	25			0-14
MF 261	270			200	200	20	2	3	20			0-14
MF 262	250			150	150	15	2	3	15			0-14
MF 333	120			100			17					4-11
MF 350	270			100	80	50	2	3	12			2-12
MF 355	250			80	60	20	1	5	15			2-12
MF 357	250			80			12					2-12
MF 360	270			150	125	70	2	3	9			1-13
MF 940	270			200	150	60	2	3	20			1-13
MG 410	550			200	100	50	1.5	1.5	20			0-14
MG 410 P	550			200	100	50	1.5	1.5	20			0-14
MG 420	600			200	100	50	1.5	2	25			0-14
MG 420 i	600			200	100	50	1.5	2	25			0-14
MG 420 P	600			200	100	50	1.5	2	25			0-14
MG 520	700			200	100	50	1	3	30			0-14
MG 780	-200 +650			310	50	20	0.5	1	10			0-14
MG 780 C	-200 +650			310	50	20	0.5	1	10			0-14
MG 780 P	-200 +650			310	50	20	0.5	1	10			0-14
MG 780 R	-200 +650			300			---					0-14
MG 787	-200 +650			350			---					0-14
MG 880 R	-200 +650			310			---					0-14
MG 1000 R	-200 +650			450			0.5	1	10			0-14
MG 970	500			200	75	35	1.5	2	30			0-14
MG 973	250			100	60	25	0.5	5	15			0-13
MG 974	300			150	75	40	1.5	2	30			1-13
MG 980	600			200	75	35	1.5	2	30			0-14
MS 315	270			250	200	80	1.5	2	15			2-12
MS 320	250			100	70	20	1	1.5	15			2-12
MS 320 G	250			100	70	20	1	1.5	15			2-12
MS 360	270			250	200	80	2	3	20			2-14
ML 730	450			100			0.5					4-8
MV 500	120			10	8	5	1	2	5			6-8